

# Legacy Series Humidifier Residential Whole-House

# **GeneralAire® Models GF-1042DMM/DMD** Flow Through Humidifier

# **Spec Sheet**

GF-1042DMM	
Туре	Flow-Through Humidifier
GPD (Based on 120° Plenum Temperature)	17
Dimensions (Inches)	14 H x 15.125 W x 9 D
Weight (Pounds)	13
Replacement Vapor Pad® (Replace Once Each Season)	GF-990-13
Home Size (Sq. Ft.)	To 2,800
Installation	Warm Air / Return Air Plenum / Right of Left Side
Plenum Opening (Inches)	13.625 W X 9.5 H
Bypass Opening (Inches)	6
Pallet Qty.	30
Cabinet Construction	UV-Stable Automotive Grade Plastic
Humidistat	GF-MHX3 (Included with GF-1042DMM)
Optional Humidistat	GF-X3 (Included with GF-1042DMD)
Voltage (Volts)	24
Warranty (Years)	5
Typical Installation	For newer homes up to 2,800 square feet and homes with a forced-air heating system
In The Box	Humidifier, humidistat, Installation Instructions, Vapor Pad <sup>®</sup> , Parts Kit, Drain Hose, Transformer, Metal Distributor Tube, Damper, 15'-5/8" Drain Hose, Drain Pan, Solenoid Valve, Quick Connect Tee valve w/Shut Off



**GF-1042DMM** 



GF-MHX3 Manual Humidistat Included in GF-1042DMM

#### **Accessories**



GFX4 Automatic Humidistat Controls the Furnace Blower Motor



GF-990-53 Solenoid Valve

Our Brands **General** Aire



Last Updated: 01-2022



400 Midwest Rd. Toronto, ON M1P 3A9 Canada Toll Free: (888) 216-9184 www.generalaireiaq.ca sales@GeneralAirelAQ.ca



# **Legacy Series Humidifier**

**Residential Whole-House** 

## **GeneralAire® Models GF-1042DMM/DMD** Flow Through Humidifier


# **Spec Sheet**

#### **Models GF-1042DMM Features**

- Model GF-1042DMM accomodates up to 2800 square feet.
- Cover is UV stable.
- Stainless steel distributor tube allows for either cold or hot water supply.
- GF-MHX3 manual control humidistat is included.
- A long-standing model; considered the "work horse" of humidifiers.

#### Installation

Vertical plenum surface of any forced air furnace



#### **Installation Options:**

- Warm Air Plenum
- Return Air Plenum
- Right or Left Bypass
- Vertical or Horizontal
- Furnace or Air Handler

### **Installs Quickly & Easily**

#### **Maintenance**

Change the Vapor Pad® at least once per year.

#### **Product Support**

- Installation Manual
- Home Owner Brochure
- Competitive Comparison
- www.GeneralAirelAQ.ca
  - Maintenance Video
  - **Help Topics**
  - **Product Information**
- Tech Support (888) 216-9184



GF-990-13 Vapor Pad®



Last Updated: 01-2022





